Quick Guide Manual

Enter the Registration Mode

- Not inputting anything for 10 seconds will cancel the authorisation.
- An error will occur if you enter a password with less than 6 digits or more than 12 digits and the authorisation will be cancelled.
- When entering an administrator password, pressing the [*] button will reset the entry.
- Pressing the [#] button without any entry or pressing the [Register] button during authorisation will cancel the authorisation.

Authorise with an Administrator Password

1. Press the [Register] button
2. Input an administrator password
3. Press the [#] button

R | Admin Password | #

Authorise with an Administrator RFID Card

1. Press the [Register] button
2. Put an adimistrator RFID card on the reader

R | CARD

*** Default password : 123456**

- For all settings such as changing the password or registration of the card/fingerprint and deletion of any authentication, you must enter "Registration Mode" first and follow up the next step.
- The initial master mode is set to "R Button Input - Initial Password (123456) - #".
- Please change the administrator password and register the administrator card to set the master mode before using it.

Register Password

- **Default password: 123456**
- Administrator password cannot be identical to an existing user/one-time password.
- Make sure to register a password while the door is open.

Step.1
Enter the **Registration Mode**

R | Admin Password | # or R | CARD

- Repeating step 3 before the keypad lamp turns off will register another user password. (Up to 4 passwords can be registered.)

2.	3.	4.	
0	Admin Password (6-12 digits)	#	Change Administrator Password
1	User Password (4-12 digits)	#	Register a User Password

* Up to 4 passwords can be registered.

1	Address (1-4)	* Select and press an address among 1-4.	#	User Password (4-12 digits)	#	Register a User Password with an Address
4	One-time Password (6 digits)	#	Register a One-time Password		

Register 3D Facial Recognition

Step.1
Enter the **Registration Mode**

R | Admin Password | # or R | CARD

6	*	Facial recognition camera	Register 3D Facial Recognition
Admin Password	*	*	2	IR Sensor Settings

- Press desired settings as below

1 Enabled | 2 Disabled | * End

Register RFID card / Fingerprint

Step.1
Enter the **Registration Mode**

R | Admin Password | # or R | CARD

- **Default password: 123456**
- Administrator password cannot be identical to an existing user/one-time password.
- Make sure to register a RFID card while the door is open.

- Repeating step 3 before the keypad lamp turns off will register another administrator RFID card. (Up to 10 RFID cards can be registered)

2.	3.	
2	CARD	Register a User RFID Card

* Repeating before the keypad lamp turns off will register another administrator RFID card.
* Up to 100 RFID cards can be registered.

2	Address (1-100)	#	CARD	Register a User RFID Card with an Address

* Select and press an address from 1 to 100.
* Up to 100 RFID cards can be registered.

- Before the number pad light turns off, repeat the 2nd step to continue registering fingerprints.

3	Fingerprint (6 times)	#	Register Fingerprint 6 Times Front / Back side 3 times each

* Up to 100 fingerprints can be registered.

3	Address (1-100)	#	FP (6 times)	#	Register Fingerprint with an Address

How to Pair Gate Lock with the door lock

Step 1 [Gate Lock]

1. 
2. Admin Password (6-12 digits)
3. *
4. 1

Step 2 [Door Lock]

5. Enter the **Registration Mode**

Step 3 [Gate Lock]

6. Password or RFID card or Fingerprint

How to Unpair Gate Lock with the door lock

Step 1 [Gate Lock]

1. 
2. Admin Password (6-12 digits)
3. *
4. 4

Step 2 [Door Lock]

5. Enter the **Deletion Mode.**
6. 5
7. *

Enter the Deletion Mode

- Not inputting anything for 10 seconds will cancel the authorisation.
- An error will occur if you enter a password with less than 6 digits or more than 12 digits and the authorisation will be cancelled.
- When entering an administrator password, pressing the [*] button will reset the entry.
- Pressing the [#] button without any entry or pressing the [Register] button during authorisation will cancel the authorisation.

Authorise with an Administrator Password

1. Press the [Register] button
2. Input an administrator password
3. Press the [#] button

R Admin Password # (for 3 seconds)

*** Default password : 123456**

Delete a RFID Card

Step.1

Enter the **Deletion Mode**

R Admin Password # (for 3 seconds) or R (for 3 seconds) CARD

2. 3. 4.

- 2 — Adderess (1-100) — * — Delete a User RFID Card with an Address
- 2 — CARD — Delete a User RFID Card
- 2 — # for 3 seconds — Delete all User RFID Cards

Delete a Password / Fingerprint

Step.1

Enter the **Deletion Mode**

R Admin Password # (for 3 seconds) or R (for 3 seconds) CARD

2. 3. 4.

- 1 — Address (1-4) — * — Delete a Password
  * Select and press an address among 1-4.
- 1 — # for 3 seconds — Delete all User Passwords
- 4 — * — Delete a One-time Password
- 3 — # for 3 seconds — Delete all Fingerprints
- 3 — Address (1-100) — * — Delete Fingerprints and Address

Setting Mode

Step.1

Touch the number pad and Input an administrator password



Admin Password

2. 3. 4.

- * * 4 — Auto Lock Mode
- * * 7 — Manual Lock Mode
- * * 8 — Disable the [#] button in Manual Lock Mode
- * * 9 — Enable the [#] button in Manual Lock Mode
- * * 0 — Activate the Virtual Number Function
- * * 1 — Auto Detection with RFID Card
- * * 3 — Manual Detection with RFID Card

Step.1

Touch the number pad and Input an administrator password



Admin Password

2. 3.

- * 3 — Volume Up
- * 6 — Voume Down
- * 2 — Enable Door Unlock Alarm
- * 0 — Disable Door Unlock Alarm